




CAUTION: PLEASE FOLLOW THIS INSTRUCTION MANUAL CAREFULLY TO PREVENT ANY INJURIES OR COMPLICATIONS THAT MAY ARISE.


WARNING: Before installing or maintaining the luminary, make sure all powers are **TURNED OFF**.

Verify that supply voltage is correct by comparing it with the label information on all fixtures. Make all connections in accordance with the NEC requirements, and make sure all luminaries are properly secured to prevent any wire complications.











3. All wiring connections must be made inside a Junction Box.


Make sure to choose the correct junction box for the desired application. Some junction boxes are made for outdoor applications and others are made for indoor applications.




4. All fixtures also come with a Safety Cord used as an extra precaution to prevent any accidents.


The Safety Cord is pre-installed in the fixture and should be able to be connected to the chain which is firmly installed to the ceiling or surface.









	PART NO.	DESCRIPTION	QTY		PART NO.	DESCRIPTION	QTY
1		ACFLSF- Slipfitter Mount, Slip-fits over a 2" pole or tenon (2.375" O.D.)	1	4		10-00046- Machine Bolt M8-1.25 x 15 mm Hex Head	2
2		10-00047- Waterproof Cable Gland	1	5	0	10-00040- Washer for M8-1.25 Bolt	2
3		10-00028- M8-1.25 x 16 mm Socket Head Machine Bolt	2				,




1. Loosen the (2) M8-1.25 Hex Head Bolts from the ACFLSF Slipfitter mount. Align the ACFLSF Slipfitter to the fixture handle and fasten the two pieces together using the [2] Hex Head Bolts and washers.





- 3. The hole on top of the Slipfitter is used to mount a waterproof cable gland. This is used to get the AC Input cable from the luminaire into the slipfitter.
- 4. The Slipfitter should be mounted onto a hollow round 2" part with AC Power cords running inside of it. Make sure all powers are off. Follow the wiring diagram provided in order to install the luminaire to the AC Power Supply.



CAUTION: PLEASE FOLLOW THIS INSTRUCTION MANUAL CAREFULLY TO PREVENT ANY INJURIES OR COMPLICATIONS THAT MAY ARISE.


WARNING: Before installing or maintaining the luminary, make sure all powers are **TURNED OFF**.

Verify that supply voltage is correct by comparing it with the label information on all fixtures. Make all connections in accordance with the NEC requirements, and make sure all luminaries are properly secured to prevent any wire complications.


"ON FIXTURE" SLIPFITTER MOUNT


PART NO.	IMAGE	DESCRIPTION	QTY
ACHWSF	Caa	"On Fixture" Slipfitter Mount, Slip-fits over a 2" pole tenon (2.375").	1

STEP 1: Using an Allen Screw, Remove the [4] Socket head Machine bolts from the back side of the High Bay luminaire.




STEP 2: Fasten the ACHWSF part with the [4] mounting holes using the same socket head machine bolts that were removed in Step 1.






STEP 3: Using the M12 Machine Screw, Run the cables from the fixture, through the ACHWSF Slipfitter.




STEP 4: Before completely tightening the two parts of the slip-fitter together, make sure to orient the angle designed. Once you have adjusted the Slip-fitter to the desired orientation, fasten the M12 bolt.





90° REFLECTOR

PART NO.	IMAGE	DESCRIPTION	QTY
ACHWRF90	0	90° REFLECTOR	1
10-00070		M5-0.8 Thread x 18 mm Long	3




STEP 2: Using a Phillips Screw Driver, Fasten the [3] provided machine screws from the inside portion of the 90° reflector to secure it into place.





- 1) Remove the two [2] #4-40 PHMS from the ACHUMO-MB bracket of the ACHUMO and remove the small phillips screw from underneath the sensor in order to replace the ACHUMO bracket with the ACHUMO3-MB. Using a Phillips screw driver (preferable with a magnetic tip), Fasten the bracket onto the FHW luminaire and use the hexnuts provided to lock it in place.
- Remove the ACHUPS sensor from the ACHUPS-MB, and install the sensor to the ACHUMO3-MB. Make sure the orientation of the sensor is the same as the day harvesting detector.
- Use the Wire Diagram provided for the required connections. Make sure all wiring connections are made inside the J-Box provided and are properly sealed by an authorized electrician.
- 4) Refer to the Individual installation sheets for the ACHUMO and the ACHUPS for adjusting the settings on the Microwave sensor and the Daylight Harvesting Detector



MICROWAVE OCCUPANCY DETECTION & DAYLIGHT HARVESTING SENSOR

PART NO.	IMAGE	DESCRIPTION	QTY
ACHUPS		Photocell/Daylight harvesting Sensor,1-10Vdc Dim down/up according to ambient brightness level, target light level adjustable. lp20 rated.	1
ACHUMO		Microwave occupancy sensor with J-Box	1
ACHUMO3-MB	Y	Mounting Bracket for the ACHUMO Microwave Sensor and ACHUPS Daylight Harvesting Sensor to the FHW luminaire.	1
10-00033		#4-40 Pan Head Machine Screw	2
10-00033		#4-40 Hex Nut	2





CAUTION: PLEASE FOLLOW THIS INSTRUCTION MANUAL CAREFULLY TO PREVENT ANY INJURIES OR COMPLICATIONS THAT MAY ARISE.

WARNING: Before installing or maintaining the luminaire, make sure all powers are **TURNED OFF**. Verify that the supply voltage is correct by comparing it with the label information on all fixtures. Make all connections in accordance with the NEC requirements, and make sure all luminaries are properly secured to prevent any wire complications. This luminaire is not to exceed the maximum ambient temperature rating noted on the specification sheet.


When ACHUMO microwave sensor works together with the ACHUPS daylight harvesting sensor, the lighting fixture will dim the light in response to the available daylight in the area when the area is being occupied.

When the customer orders the ACHUMO and the ACHUPS, a special mounting bracket will also be included (ACHUMO3-MB). This mounting bracket is specifically made to be able to mount both the sensor and occupancy detector simultaneously. Each luminaire already comes with two holes made specifically for this bracket.





THIS DIAGRAM IS A
RECOMMENDATION ON HOW TO
INSTALL THE WIRING INSIDE THE
JUNCTION BOX. APPLY WATERPROOF
SEALANT AFTER ALL WIRING IS
COMPLETE.




DAYLIGHT HARVESTING SENSOR




CAUTION: PLEASE FOLLOW THIS INSTRUCTION MANUAL CAREFULLY TO PREVENT ANY INJURIES OR COMPLICATIONS THAT MAY ARISE.

WARNING: Before installing or maintaining the luminaire, make sure all powers are **TURNED OFF**. Verify that the supply voltage is correct by comparing it with the label information on all fixtures. Make all connections in accordance with the NEC requirements, and make sure all luminaries are properly secured to prevent any wire complications. This luminaire is not to exceed the maximum ambient temperature rating noted on the specification sheet.

INSTALLATION STEPS



PART NO.	IMAGE	DESCRIPTION	QTY
ACHUPS		Photocell/Daylight harvesting Sensor,1-10Vdc Dim down/up according to ambient brightness level, target light level adjustable. Ip20 rated.	1
ACHUPS-MB		Mounting Bracket for the ACHUPS Photocell Sensor	1
10-00032		#4-40 Pan Head Machine Screw	2
10-00033		#4-40 Hex Nut	2



- 1) Remove the two [2] #4-40 PHMS from the mounting bracket. Using a Phillips screw driver (preferable with a magnetic tip), Fasten the bracket onto the FHW luminaire (all fixtures have two small holes specifically made for the ACHUPS-MB bracket and use the hexnuts provided to lock it in place.
- 2) Refer to the wiring diagram to connect the ACHUPS to the Dimmable LED Driver.
- 3) Make sure all wiring connections are made inside a J-Box. Since the Daylight Harvesting Sensor is to only be used indoors. It must be an Indoor J-Box.

4) On the photocell, there is a small adjustable knob with a (+) and (-) sign, this knob is the Potentiometer for adjusting the light level desired. It is recommended for the target light level to be between 40% to 80% of the total lux of luminaires.




CAUTION: PLEASE FOLLOW THIS INSTRUCTION MANUAL CAREFULLY TO PREVENT ANY INJURIES OR COMPLICATIONS THAT MAY ARISE.

WARNING: Before installing or

maintaining the luminary, make sure all powers are TURNED OFF.

Verify that supply voltage is correct by comparing it with the label information on all fixtures. Make all connections in accordance with the NEC requirements, and make sure all luminaries are properly secured to prevent any wire complications.

INSTALLATION STEPS





- 2) Refer to the wiring diagram provided to connect the ACHUMO to the Dimmable LED Driver. Try to aim the sensor toward the desired detectable area.
- 3) Make sure all wiring connections are made inside the J-Box provided and are properly sealed by an authorized electrician.
- 4) Remove the screw and cap of the sensor and adjust the DIP switches to get the desired settings. Sensor data can be precisely set for each specific application. Once the program is set, close and fasten the cap.



MICROWAVE OCCUPANCY DETECTION

			_
PART NO.	IMAGE	DESCRIPTION	QTY
ACHUMO		Microwave occupancy sensor with J-Box	1
ACHUMO-MB4		Mounting Bracket for the ACHUMO occupancy sensor	1
10-00032		#4-40 Pan Head Machine Screw	2
10-00033		#4-40 Hex Nut	2





IV

10%

(1) DETECTION AREA

Detection area can be reduced by selecting the combination on the DIP switches to fit precisely each application

(2-4) HOLD TIME

Refer to the time period the lamp remains at 100% illumination after no motion detected

(8-9) STAND-BY DIMMING LEVEL

The low light level you would like to have after the hold time in the long absence of people

		5	6	7	
		ON	ON	ON	60m+
ON	ll.	-	ON	ON	60min
	III	ON	-	ON	30min
	IV	-	-	ON	10min
	V	ON	ON	-	5 min
	VI	-	-	-	5 s

		10	11	12	
ON		ON	ON	ON	Disable
		-	ON	-	20 lux
	Ш	ON	-	-	10 lux
	IV	-	-	-	5 lux


(5-7) STAND-BY PERIOD

Refer to the time period the lamp remains at 100% illumination after no motion detected

(10-12) DAYLIGHT SENSOR

The sensor can be set to only allow the lamp to illuminate below a defined ambient brightness threshold.

When set to Disable mode, the daylight sensor will switch on the lamp when motion is detected regardless of ambient light level. Note that daylight sensor is active only when lamp totally switches off.




PIR OCCUPANCY DETECTION





CAUTION: PLEASE FOLLOW THIS INSTRUCTION MANUAL CAREFULLY TO PREVENT ANY INJURIES OR COMPLICATIONS THAT MAY ARISE.

WARNING: Before installing or maintaining the luminaire, make sure all powers are **TURNED OFF.** Verify that the supply voltage is correct by comparing it with the label information on all fixtures. Make all connections in accordance with the NEC requirements, and make sure all luminaries are properly secured to prevent any wire complications. This luminaire is not to exceed the maximum ambient temperature rating noted on the specification sheet.



PART NO.	IMAGE	DESCRIPTION	QTY
ACHUOS		Passive infrared occupancy sensor, 120-277v. Adjustable Timer and Sensitivity. Includes the ACHUOS NUT. Indoor Use Only	1
ACHUOS-MB	Q	Mounting Bracket for the ACHUOS Photocell Sensor	1
10-00032		#4-40 Pan Head Machine Screw	2
10-00033		#4-40 Hex Nut	2





The ACHUOS comes with a black mounting bracket made specifically to be installed with the luminaire. Each luminaire already comes with a hole made specifically for this bracket.

- 1)Make sure all Powers are OFF.
- 2) Remove the custom gear-shaped washer in order to remove the mounting bracket from the ACHUOS sensor. Be sure to not misplace any parts since they will all have to be used for later steps.
- 3) Remove the two [2] #4-40 PHMS from the mounting bracket. Using a Phillips screw driver (preferable with a magnetic tip), Fasten the bracket onto the luminaire and use the hexnuts provided to lock it in place.
- 4) Once the mounting bracket is fastened onto the fixture, one can now mount the sensor onto the bracket using the same custom gear-shaped washer.
- 5) Refer to the wiring diagram provided to connect the ACHUOS to the LED Driver.
- 6) Make sure all wiring connections are made inside a J-Box and are properly sealed by an authorized electrician.
- 7) Seal the sensor opening to prevent any liquids from entering
- 8) Adjust the [3] knobs to get the desired setting.